



MOBELARIS

CARE INSTRUCTION GUIDE

At Mobelaris, our philosophy begins with an unbridled passion for timeless Scandinavian design that provides our clients with products chosen based on high-quality craftsmanship and premium materials.

Each piece is designed to stand the test of time and age beautifully in your home. In order to take the best care possible, we have put together a selection of care instructions which will help guide you when caring for your special pieces at home.



DISCLAIMER

The cleaning and maintenance instructions written in this document are only guidelines. We advise that all our wonderful clients seek professional advice before attempting the below to maintain the longevity and appearance of each piece.

Mobelaris does not assume any responsibility for the use of these instructions, and all responsibility lies with the consumer. Incorrect use of the care instructions is not covered by the warranty.



EVERYDAY MAINTENANCE TIMBER FURNITURE

When choosing the final location for your product be mindful of environmental factors such as heat sources, pets and humidity as they will all have an effect on your furniture. Do not place in direct sunlight as this may cause fading and structural movement.

While caring for your Mobelaris products, use a warm damp sponge and diluted, non-abrasive detergent to clean any dust or small spills. Ensure any excess water is wiped off using a soft microfiber cloth. It is important to avoid placing abrasive objects on timber.

SOAP TREATED AND UNTREATED



Only solid wood furniture is available untreated. Untreated wooden surfaces are very sensitive to dirt, fat and liquids. Very humid environments can raise the fibres in the wood, which makes the surface less smooth.

Coloured liquids can cause very deep spots.

Both untreated and soap treated wood age very beautifully. As the surface becomes more treated through every day use and washing in soap solutions, it will also grow more resistant to dirt.

DAILY CLEANING

- Use a clean dry soft cloth
- Lukewarm water and wrung well
- Wipe clean ensuring no excess water remains
- Dirt and spots of oils should be removed with a light solution of soap water

MAINTENANCE

- Twice per year, furniture should be washed with a soap solution
- Please seek a professional to soap the furniture and to advise what products you should use.
- Ensure your furniture is wiped clean of any dust with a soft damp cloth
- After the spots have been removed the entire wooden surface must be covered in the soapy solution using a cloth
- Distribute the soap solution evenly to all surfaces, but be careful not to soak the furniture
- Dry off with a soft cloth wrung well and following the direction of the grain

SOAP FLAKE RECOMMENDATIONS



For many of the materials in our range, we recommend using boiled, then cooled water, to which pure soap flakes should be added for more thorough cleaning. It is important to take care when choosing soap flakes, as many manufacturers add chemical additives that may react negatively with natural materials such as leather and wood.

- Use white natural soap flakes- never brown soap
- Use soap flakes that are free of bleaches or lighteners
- Use soap flakes that are free of perfumes
- If in doubt, use organic soap flakes that are allergy- tested and free of any added substances such as fragrances